

## 8A, 17V Synchronous Step-Down Converter

### **General Description**

This document explains the function and use of the RTQ2823A evaluation board (EVB), the RTQ2823A is a high-performance, synchronous step-down converter that can deliver up to 8A output current with an input supply voltage range of 4.5V to 17V. The device integrates low  $R_{DS(ON)}$  power MOSFETs, accurate 0.6V reference and an integrated diode for bootstrap circuit to offer a very compact solution. This document explains the function and use of the RTQ2823A evaluation board (EVB), and provides information to enable operation, modification of the evaluation board and circuit to meet individual requirements.

### **Table of Contents**

General Description .....	1
Performance Specification Summary .....	2
Power-up Procedure .....	2
Detailed Description of Hardware .....	3
Bill of Materials .....	5
Typical Applications .....	6
Evaluation Board Layout .....	9
More Information .....	11
Important Notice for Richtek Evaluation Board .....	11

## Performance Specification Summary

Summary of the RTQ2823AGQVF Evaluation Board performance specification is provided in Table 1. The ambient temperature is 25°C.

Table 1. RTQ2823AGQVF Evaluation Board Performance Specification Summary

Specification	Test Conditions	Min	Typ	Max	Unit
<b>Default Input Voltage</b>	Default = 12V	4.5	12	17	V
<b>Output Voltage</b>	Default = 1.2V	0.6	--	5.5	V
<b>Maximum Output Current</b>		--	--	8	A
<b>Operation Frequency</b>	Default = 800kHz	400	800	1200	kHz
<b>Soft-Start Time</b>	Css = 47nF	--	4.7	--	ms

## Power-up Procedure

### Suggestion Required Equipments


- DC Power Supply (Chroma, 62006P-100-25)
- Electronic load capable of 30A
- Four Channels Digital Real-Time Oscilloscope
- Display Multi-meter (34405A)

### Power-up & Measurement Procedure

1. Apply a 12V nominal input power supply ( $4.5V < V_{IN} < 17V$ ) to the VIN and GND terminals.
2. Set the jumper at JP1 to connect terminals H and EN, connecting EN to VIN through resistor R18 (100kΩ). The Enable pin can connected to VIN directly as well to enable operation.
3. Set the jumper at JP2 to connect terminals H and PGOOD, Connecting VCC to H through resistor RPGOOD (100kΩ).
4. Verify the output voltage (approximately 1.2V) between VOUT and GND.
5. Connect an external load up to 8A to the VOUT and GND terminals and verify the output voltage and current.

**Detailed Description of Hardware**

**Headers Description and Placement**



Carefully inspect all the components used in the EVB according to the following Bill of Materials table, and then make sure all the components are undamaged and correctly installed. If there is any missing or damaged component, which may occur during transportation, please contact our distributors or e-mail us at [evb\\_service@richtek.com](mailto:evb_service@richtek.com).

**Test Points**

The EVB is provided with the test points and pin names listed in the table below.

Test point/ Pin Name	Function
<b>EN</b>	Enable Control Input
<b>MODE</b>	Current limit, switching frequency, and light load operation mode selection pin.
<b>BOOT</b>	Bootstrap
<b>SW</b>	Switch node
<b>PGND</b>	Power ground
<b>VIN</b>	Input voltage
<b>VCC</b>	4.7V internal LDO output
<b>AGND</b>	Analog GND
<b>PGOOD</b>	Power good indicator output
<b>SS</b>	Soft-start time control pin


**Bill of Materials**

Reference	Qty	Part Number	Description	Package	Manufacturer
U4	1	RTQ2823AGQVF	Step-Down DC-DC Converter	VQFN-18L 3.5x3.5 (FC)	RICHTEK
C1, C2, C7, C15	4	0603B104K500CT	0.1 $\mu$ F, 50V, X7R	0603	WALSIN
C3, C4, C5, C6	4	GRM21BR61E226ME44L	22 $\mu$ F, 25V, X5R	0805	MURATA
C11, C12, C13, C14	4	GRM32ER61C476KE15L	47 $\mu$ F, 16V, $\pm$ 20%, X5R,	1210	MURATA
C16	1	0603N101J500CT	100pF, 50V, NPO	0603	MURATA
C17	1	GRM188R71C473KA01	0.047 $\mu$ F, 16V, $\pm$ 10%, X7R	0603	MURATA
C19	1	GRM188R61E475KE11D	4.7 $\mu$ F, 10V, $\pm$ 20%, X5R	0603	MURATA
L1	1	744311068	0.68 $\mu$ H, R <sub>DC</sub> = 3.1m $\Omega$	7.0x7.0x4.0	WURTH ELEKTRONIK
R1, R14 R16	3	WR06X000 PTL	RES, 0, 1%, 0.1W	0603	WALSIN
R13, R17	2	WR06X1002FTL	RES, 10k, 1%, 0.1W	0603	WALSIN
R18, R19 RPGOOD1	3	WR06X1003FTL	RES, 100k, 1%, 0.1W	0603	WALSIN
RMODE1	1	WR06X1203FTL	RES, 120k, 1%, 0.1W	0603	WALSIN
RMODE2	1	WR06X2002FTL	RES, 20k, 1%, 0.1W	0603	WALSIN

## Typical Applications

### EVB Schematic Diagram

RTQ2823A demo board:  $V_{IN} = 12V$ ,  $V_{OUT} 1.2V / 8A$



#### Note :

1. The capacitance values of the input and output capacitors will influence the input and output voltage ripple.
2. MLCC capacitors have degrading capacitance at DC bias voltage, and especially smaller size MLCC capacitors will have much lower capacitance than specified.
3. Set default soft start time 5ms by connecting C17 to 47nF.



**Measurement Results**

Output Ripple Measurement		Output Ripple Measurement	
 <p><math>V_{OUT}</math> (10mV/Div)</p> <p><math>V_{IN} = 12V, V_{OUT} = 1.2V, I_{OUT} = 10mA</math></p> <p><math>V_{SW}</math> (5V/Div)</p> <p>Time (200µs/Div)</p>	 <p><math>V_{OUT}</math> (10mV/Div)</p> <p><math>V_{IN} = 12V, V_{OUT} = 1.2V, I_{OUT} = 8mA</math></p> <p><math>V_{SW}</math> (5V/Div)</p> <p>Time (1µs/Div)</p>	<p>Output ripple at 10mA load: 32mVpp</p>	<p>Output ripple at 8A load: 10mVpp</p>
Output Ripple Measurement		Output Ripple Measurement	
 <p><math>V_{OUT}</math> (10mV/Div)</p> <p><math>V_{IN} = 12V, V_{OUT} = 5.5V, I_{OUT} = 10mA</math></p> <p><math>V_{SW}</math> (5V/Div)</p> <p>Time (100µs/Div)</p>	 <p><math>V_{OUT}</math> (10mV/Div)</p> <p><math>V_{IN} = 12V, V_{OUT} = 5.5V, I_{OUT} = 8mA</math></p> <p><math>V_{SW}</math> (5V/Div)</p> <p>Time (1µs/Div)</p>	<p>Output ripple at 10mA load: 27mVpp</p>	<p>Output ripple at 8A load: 10mVpp</p>
Dynamic Load 10mA to 8A Load Step (DCM mode)		Dynamic Load 10mA to 8A Load Step (FPWM Mode)	
 <p><math>V_{OUT}</math> (20mV/Div)</p> <p><math>V_{IN} = 12V, V_{OUT} = 1.2V, \text{Frequency} = 800k</math></p> <p><math>I_{OUT}</math> (4A/Div)</p> <p>Time (100µs/Div)</p>	 <p><math>V_{OUT}</math> (20mV/Div)</p> <p><math>V_{IN} = 12V, V_{OUT} = 1.2V, \text{Frequency} = 800k</math></p> <p><math>I_{OUT}</math> (4A/Div)</p> <p>Time (100µs/Div)</p>	<p>VPK-PK: 40mV</p>	<p>VPK-PK: 39mV</p>



Start-Up Measurement from Enable

Power-Off Measurement from Enable





Start-up time 5ms. Soft-start 5ms.

Vout discharge during power-off

Start-Up Measurement from VIN

Power-Off Measurement from VIN



Start-up time 2.7ms. Soft-start 1.575ms.

VOUT discharge during power-off



**Evaluation Board Layout**

Figure 1 to Figure 4 are RTQ2823AGQVF Evaluation Board layout.




Figure 1. Top View (1<sup>st</sup> layer)




Figure 2. PCB Layout—Inner Side (2<sup>nd</sup> Layer)




Figure 3. PCB Layout—Inner Side (3<sup>rd</sup> Layer)




Figure 4. Bottom View (4<sup>th</sup> Layer)

### ***More Information***

For more information, please find the related datasheet or application notes from Richtek website <http://www.richtek.com>.

### ***Important Notice for Richtek Evaluation Board***

THIS DOCUMENT IS FOR REFERENCE ONLY, NOTHING CONTAINED IN THIS DOCUMENT SHALL BE CONSTRUED AS RICHTEK'S WARRANTY, EXPRESS OR IMPLIED, UNDER CONTRACT, TORT OR STATUTORY, WITH RESPECT TO THE PRESENTATION HEREIN. IN NO EVENT SHALL RICHTEK BE LIABLE TO BUYER OR USER FOR ANY AND ALL DAMAGES INCLUDING WITHOUT LIMITATION TO DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES.